

The 0.5° Angle-Spacer **substitutes** the regular **crown race** and is mounted **between the fork crown and headset** on your **Tapered Fork** and fits with standard **45° headset bearings**.

Please keep in mind the assembly height of 10mm, you may need to remove a stem spacer to adjust for the change in height.

To avoid damage to your fork or the Angle Spacer, we recommend that the fitting should be done by a professional bike shop.

Installation Instructions-

1. Loosen star nut and stem bolts.
2. Slide fork steerer out of the headtube of your frame.
3. Remove standard crown race from your fork.
4. Slide the 0.5° Angle-Spacer onto the fork steerer, in place of the normal crown race. Ensure it is the correct way round with the decals readable.
5. Slide the fork steerer back into the headtube of the frame.
6. At this stage you may want to adjust your stack height with your stem spacers to your preference.
7. Tighten star nut and stem bolts and check that everything is tight.

